



INSTALLATION INSTRUCTIONS FOR
MEGASHIFTER™
SHORT STICK KIT
Part No. 80695
 for B&M Universal and Console MegaShifters



DESCRIPTION	QTY
STICK, SHORT	1
TRIGGER ROD, SHORT	1
WASHER, FLAT 1/4"	1
HAIR PIN	1
BUSHING, NYLON	1

INTRODUCTION

This kit provides a short stick option for universal MegaShifters:

- 80690 (standard)
- 80680 (light truck)
- 80685 (right-hand drive)

It is also an OEM replacement stick for console MegaShifters:

- 80692 (1982-92 Camaro & Firebird)
- 80694 (1973-81 Camaro & 1970-81 Firebird)
- 81035 (1968-69 Camaro)

Before starting, take the time to read and understand these instructions. Installation requires minimal mechanical knowledge & skills. If you do not understand any part of these instructions, please call **B&M Technical Support at (866) 464-6553** for assistance.


Use the parts list to verify your kit's contents. In the unlikely event that any parts are missing, please contact B&M Technical Support for replacements.

REQUIRED SUPPLIES


- Medium strength thread-locking fluid (Permatex Blue or equivalent)

INSTALLATION


1. **Set the vehicle's parking brake.** Loosen the jam nut, then remove the T-handle and jam nut.
2. **Work the rubber boot's lower groove** off of the chrome cover assembly. Work the boot up and over the shift lever, disengage its upper groove from the chrome flange, and carefully remove the boot from the lever.



3. **Place a fingertip under the trigger rod** to catch the washer, then pull the hair pin with needle-nose pliers, and set the pin and washer aside. **NOTE:** The kit includes a spare hair pin and washer, if needed.




4. **Remove the trigger rod**, then remove the trigger return spring. **NOTE:** To avoid losing the spring when removing it, grasp it tightly, as it is under compression.
5. **Remove the 2 stick screws**, then remove the stick from the shifter.



6. From the kit, assemble the black trigger bushing and the new stick, then insert the stick in the shifter. Apply thread locking fluid to the 2 screws, then install and tighten the screws.



9. Gently work the rubber boot down over the stick and work the boot's lower groove onto the chrome cover. Then work the boot's upper groove onto the stick's lower flange. (The stick has 2 flanges, and the top flange will sit atop the boot.)



7. Insert the trigger return spring between the yoke and the stick. Then insert the new trigger rod down through the stick and spring, and into the yoke.


10. Run the jam nut all the way down the stick's threads. Then apply thread locking fluid to the stick threads.

CAUTION: If thread locking fluid is not used, the T-handle's threads may gall, making it impossible to remove it from the stick in the future.

11. Carefully thread the T-handle all the way onto the stick.

CAUTION: Avoid cross-threading! The T-handle should spin freely onto the stick with no resistance. If you start to feel any resistance, STOP, remove the handle, align the threads properly, and try again.

Align the T-handle as desired, then tighten the jam nut.



8. Install the washer over the tip of the trigger rod, then insert the hair pin.



Congratulations! Your B&M short MegaShifter stick is now installed and ready to enjoy!

KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE

B&M Performance & Off-Road maintains a highly-trained technical service department to answer your technical questions, provide additional product information and offer various recommendations.

B&M TECHNICAL SUPPORT: (866) 464-6553