




**ROCKER ARM STUD PINNING KIT  
P/N 806G**

1. Check that all studs are equal in height to be sure none have loosened.
2. Mark stud bosses 9/16" down from top face of boss.
3. Use drill supplied with kit and drill carefully so inserted pins will be flush with O.D. of boss.
4. Install roll pins by tapping with a hammer until pin is flush with boss (valve side).




**199R11560  
Date: 4-19-18**



**ROCKER ARM STUD PINNING KIT  
P/N 806G**

1. Check that all studs are equal in height to be sure none have loosened.
2. Mark stud bosses 9/16" down from top face of boss.
3. Use drill supplied with kit and drill carefully so inserted pins will be flush with O.D. of boss.
4. Install roll pins by tapping with a hammer until pin is flush with boss (valve side).




**199R11560  
Date: 4-19-18**



**ROCKER ARM STUD PINNING KIT  
P/N 806G**

1. Check that all studs are equal in height to be sure none have loosened.
2. Mark stud bosses 9/16" down from top face of boss.
3. Use drill supplied with kit and drill carefully so inserted pins will be flush with O.D. of boss.
4. Install roll pins by tapping with a hammer until pin is flush with boss (valve side).




**199R11560  
Date: 4-19-18**



**ROCKER ARM STUD PINNING KIT  
P/N 806G**

1. Check that all studs are equal in height to be sure none have loosened.
2. Mark stud bosses 9/16" down from top face of boss.
3. Use drill supplied with kit and drill carefully so inserted pins will be flush with O.D. of boss.
4. Install roll pins by tapping with a hammer until pin is flush with boss (valve side).




**199R11560  
Date: 4-19-18**



**ROCKER ARM STUD PINNING KIT  
P/N 806G**

1. Check that all studs are equal in height to be sure none have loosened.
2. Mark stud bosses 9/16" down from top face of boss.
3. Use drill supplied with kit and drill carefully so inserted pins will be flush with O.D. of boss.
4. Install roll pins by tapping with a hammer until pin is flush with boss (valve side).




**199R11560  
Date: 4-19-18**



**ROCKER ARM STUD PINNING KIT  
P/N 806G**

1. Check that all studs are equal in height to be sure none have loosened.
2. Mark stud bosses 9/16" down from top face of boss.
3. Use drill supplied with kit and drill carefully so inserted pins will be flush with O.D. of boss.
4. Install roll pins by tapping with a hammer until pin is flush with boss (valve side).



**199R11560  
Date: 4-19-18**