


P/N 30-803



Installation Instructions for 30-803 Fuel Pressure Regulator


Installation of this regulator should follow the above illustration to route the fuel lines. The ports are 3/8" pipe thread. Use the provided mounting bracket to mount the regulator

This regulator has been preset at 6.5 P.S.I. with a certified calibrated gauge. If your gauge reads radically different from 6.5 P.S.I. then either your gauge is no longer reading correctly or there is a problem in the fuel system from operating properly.

If you have questions or any other issues please call our technical service phone line at 270-781-9741.

© 2010 QUICK FUEL TECHNOLOGY 99-30-803

P/N 30-803



Installation Instructions for 30-803 Fuel Pressure Regulator

Installation of this regulator should follow the above illustration to route the fuel lines. The ports are 3/8" pipe thread. Use the provided mounting bracket to mount the regulator

This regulator has been preset at 6.5 P.S.I. with a certified calibrated gauge. If your gauge reads radically different from 6.5 P.S.I. then either your gauge is no longer reading correctly or there is a problem in the fuel system from operating properly.

If you have questions or any other issues please call our technical service phone line at 270-781-9741.

© 2010 QUICK FUEL TECHNOLOGY 99-30-803